



2001-2006 Mini Cooper Wheel Bearing Replacement

A video tutorial on how to change the front and rear wheel bearings on a 2001-2006 Mini Cooper.

Written By: eCuration



INTRODUCTION

Instead of replacing the bearings themselves, replace the hubs for an easier install. This video will show you how to do the front and rears.



TOOLS:

- [Hydraulic Floor Jack](#) (1)
- [Jack Stand](#) (1)
- [Torque Wrench](#) (1)
- [Impact Wrench](#) (1)
- [3/8" Drive Ratchet](#) (1)
- [10" Ratchet Extension](#) (1)
- [32mm Socket](#) (1)
- [T50 Torx](#) (1)
- [7mm Socket](#) (1)
- [13mm Socket](#) (1)
- [Flathead Screwdriver](#) (1)
- [Hammer](#) (1)



PARTS:

- [Wheel Bearing and Hub Assembly](#) (1)

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-10-11 10:27:07 AM.